


KitchenAid®**OVEN PARTS**For Models: KEBS207SBL00, KEBS207SWH00, KEBS207SSS00
(Black) (White) (Stainless)30" BUILT-IN ELECTRIC
DOUBLE OVEN
THERMAL CONVECTION

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: KEBS207SBL00, KEBS207SWH00, KEBS207SSS00
(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	11	4448972	Oven Light Assembly	22	8303692	Latch, Mortorized
	8304336	Installation Instructions	12	4452164	Bulb, Light	23	4449743	Screw
	8304324	Use & Care Guide	13	3400832	Screw (2)	25	4455641	Side, Chassis
		Tech Sheet	14	W10116849	Frame, Front	26	8304303	Back, Chassis
	8303952	English	15	8304493	Gasket, Door	27		Liner, Oven (Not serviceable)
	8304416	French	16	3196176	Screw	28	8304452	Thermal Fuse 105C
	8304335	Easy Set Guide	17	4449040	Screw	29	4455636	Sensor
		Safer Cooking Tips	18	4449154	Screw	30	8303685	Vent, Center
	3191638	English	19	4451478	Support, Insulation	31	8303516	Base, Chassis
	9759133	French	20	4450038	Screw (2)	32	8304478	Retainer, Gasket
2	8304420	Bracket, Base	21		Mounting Rail, Side	33	8303517	Cover, Back
3		Hinge Receiver		8303677BL	Right Black	34		Trim, Bottom Vent
	4455606	Right		8303677WH	White		8303705WH	White
	4455605	Left			Left		8303705BL	Black
4	9760749	Bumper, Door (2)		8303678BL	Black		8303705SS	Stainless
5	8303829	Exhaust, Vent Slope		8303678WH	White	FOLLOWING PARTS NOT ILLUSTRATED		
6	8303513	Divider, Vent				INSULATION		
7	8303511	Top Chassis					8303965	Insulation, Wrap
8	4449809	Screw					8303967	Insulation, Back
9	4452158	Tube, Vent						
10	4452163	Lens, Light						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS


For Models: KEBS207SBL00, KEBS207SWH00, KEBS207SSS00
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	8303716WH 8303716BL 8303716SS	Panel, Control White Black Stainless
2	8303687	Support, Appliance Manager
3	8303797	Bracket, Glass Touch
4	8304332	Control Panel, Glass Touch
5	W10118696	User Interface
6	8303719	Backer, Control
7	8303887	Bracket, Enclosure
8	4449154	Screw
9	3400832	Screw
10	W10119142	Appliance Manager
11	8304441	Resistor, Drop

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


For Models: KEBS207SBL00, KEBS207SWH00, KEBS207SSS00
(Black) (White) (Stainless)



W10122722

INTERNAL OVEN PARTS

For Models: KEBS207SBL00, KEBS207SWH00, KEBS207SSS00
(Black) (White) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	3181534	Rack, Roasting
5	8303841	Rack, Oven
6	8303839	Oven Rack (Sliding)
7	9760768	Element, Bake
8	4455037	Tray, Bake
9	4449154	Screw
10	4450039	Cover, Bake Tray
11	4449809	Screw
12	8303962BU	Cover, Fan
13	9760769	Element Convection
14	9755543	Jack, Meat Probe
15	9755542	Probe, Meat
16	4452226	Blade, Fan
17	4452227	Nut
18	4451583	Fan, Convection
19	9755547	Washer, Lock
20	9755546	Nut, Hidden

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KEBS207SBL00, KEBS207SWH00, KEBS207SSS00
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9752759	Relay (2)
2	8303514	Duct, Air Outlet
3	4449809	Screw
4	8303972	Blower, 60mm
5	9762052	Transformer, Lights
6	8285593	Connector, Cover
7	9760212	Transformr, Control
9	4449868	Block, Terminal
10	3400080	Screw
11	8303684	Vent, Control Panel
12		Side, Control Top
	8303518	Right
	8304255	Left
13	8303520	Back, Control
14	8304219	Cover, Top
15	112432	Nut (3)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KEBS207SBL00, KEBS207SWH00, KEBS207SSS00
(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

	72017	White
	261869	Cord Brown
	72032	Black

PAINT, SPRAY

	350930	White
	261900	Citrine White
	830864	Black

ADHESIVE

	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SPLICING WIRES--25FT.

LENGTH

	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

WIRING HARNESS PARTS

	8304102	Harness, Wire (Latch)
	9762781	Harness,(Keyboard)
	8304406	Harness, Main
	8304051	Communication, Harness
	8304439	Conduit, Double
	4450800	Screw,Ground
	4448664	Clamp
	4452400	Lead, Ground
	4452222	Spacer, Harness
	4454835	Tie, Cable
	4451761	Support, Wiring
	4454842	Tie, Cable
	313438	Clip, Harness

Miscellaneous

	4448950	Screw, Install (4)
	2261590	Stainless Cleaner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST